

## Specifications:

- Compatible with All 4g GSM SIM card
- Work frequency: 850Mhz/900Mhz/1800Mhz/1900Mhz (Quad-band)
- Excellent stand by/working time and sound quality
- Voice activation, you can call back your phone automatically when the sound around it up to 45DB
- You can send message command or cancel voice activation function by easy SMS "1111" or "0000" only
- Standby time: 2-3 days (10-12 days if acoustic alarm function off)
- Working Time: 5hours
- Power supply: 24 hours non-stop
- Microphone range(Radius):5-7m
- Responding Frequency: 1.2K-800Khz

## Instructions:

1. Open the back cover, insert SIM card into the deck it will automatically boot.

Boot light is 3 seconds, after the lights go off you can dial the SIM card number.

2. Please confirm that that you have good 4g GSM network signal strength. If the signal is not 4g and is not a strong signal device may not work properly.

3. Call the SIM card number with your mobile phone or landline telephone, access voice feature by dialing "1111" dial "0000" to turn off.

4. The flashing red light indicates the SIM card is correctly inserted.

SIM will complete initialization stay in stand-by status; light will turn off when it is ready.

Dial the SIM card number; you will hear the sound around the SIM/device.

When the device is fully charged the Red LED light will turn on the Green light will turn OFF.

**\* Note:** This GSM voice/Audio monitor Bug, will NOT work on CDMA network and MAY not work on 3G network!